




JOY NEO

Ideal Standard



Pos.	Signify	Spare parts-Nr.	Quantity	Pos.	Signify	Spare parts-Nr.	Quantity
1	Handle cross-compl.	B961752XX	1 Set				
1a	Handle lever-compl.	B961754XX	1 Set				
2	Adapter+screw	A861446NU	1 Set				
3	Ceramic valve G1/2,90°-LH	A861243NU*	1 Set				
3a	Ceramic valve G1/2,90°-RH	A861244NU*	1 Set				
4	Flex hose G1/2-L400mm	B960389NU	1 Pcs.				
5	Fixation set	A964520NU	1 Set				
6	R spout-compl.	B961769XX	1 Set				
7	Aer.cache M16.5x1-5l/min	A962708NU	1 Pcs.				
8	Pull-up rod-compl.	B960900XX	1 Set				
9	Pop-up drain ass.	A961230XX	1 Pcs.				